

Instructions continued from front



STAGGERED

Follow steps 1 and 2. Great for staggered installation. No need to re-adjust.

BALDOSAS ESCALONADAS

La plantilla es ideal para instalar baldosas escalonadas. No es necesario reajustar.

ODD CUTS

Follow alphabetical guidelines to assist in marking "L" cuts, door jambs, etc.

CORTES IRREGULARES

Siga las instrucciones para marcar cortes en "L", las jambas de las puertas, etc.



NOTE: Note: Please check tiles periodically to insure proper fit. Para garantizar un corte correcto, verifique periódicamente el ancho de las baldosas.



WALL INSTALLATION

Follow Steps 1 and 2 above. There is only one thing different. It is difficult to hold the tool and tile to be cut on the wall, so lay all your full tile first. Then mark your installed wall tile. After you mark your laid tiles you can mark the piece to be cut from those lines.

INSTALACIÓN DE PARED

Siga los pasos 1 y 2 anteriores. Hay sólo una cosa diferente. Es difícil mantener la herramienta y azulejo para cortar en la pared, todo tan laico de su baldosa completa primero. Luego marque el azulejo de la pared instalado. Después de marcar sus puestos azulejos puede marcar la pieza a cortar de esas líneas.



NOTE: Please make sure you exercise caution when using the razor knife to score the vinyl. Nota: Asegúrese de que usted tenga cuidado cuando utilice la cuchilla para anotar el vinilo.

VINYL INSTALLATION

Step 1

Adjust the tool to the size of the vinyl tile and add approximately 1/8" to account for expansion. For a diagonal pattern (diamond pattern) you will need to measure your vinyl tile from corner to corner diagonally and then add 1/8".

Step 2

Set one piece of vinyl tile directly on top of the other. Position the MeasureRIGHT Pro up against the wall. Place your fingers in the MeasureRIGHT Pro slots to hold vinyl in place and score the vinyl with a razor knife or mark with pencil. Then snap the scored vinyl tile and set the cut piece. It's that easy!

INSTALACIÓN DE VINILO

Paso 1

Ajustar la herramienta al tamaño de las baldosas de vinilo y añadir aproximadamente 1/8" para dar cuenta de la expansión. Para un patrón diagonal (patrón del diamante) usted necesita medir sus baldosas de vinilo de esquina a esquina diagonal y luego añadir 1/8".

Paso 2

Coloque una pieza de baldosas de vinilo directamente encima de la otra. Coloque el MeasureRIGHT Pro contra la pared. Coloque los dedos en las ranuras de MeasureRIGHT Pro para sostener el vinilo en lugar y puntuación el vinilo con una navaja o marca con lápiz. Luego coloque las baldosas de vinilo anotada y fijar la pieza cortada. Es así de fácil!

